

TASKI[®] procarpet 45





Determine if deep cleaning (extraction) or interim cleaning (encapsulation) is required.



Fill fresh water into solution tank with a coupling hose or by using a bucket. Or fill using a dispensing system.



Depending on the application method dose the needed product into the fresh water.



Assemble the brush. Attention: Ensure you use the appropriated brush type.



completely and plug it in.





Lower the brush and suction unit by pressing the front foot pedal down. You will notice the brush and vacuum lower.



Adjust the brush position according to the carpet pile.



Adjust the working position that you feel comfortable with.



Turn on the machine by pressing the On/Off button.



Choose the application mode you need. I. for encapsulation II for deep cleaning extraction NOTE: Vacuum will only turn on during II mode.



Depending on the application method pre-spray approved product onto the floor.



Clean the floor with the machine or by using a hand tool. The triggers on the handle will activate the brush and apply solution based on application mode. NOTE: The machine



After work process is completed switch off the machine by pressing the On/ Off button.



Lift-up the brush and suction unit by pressing the foot pedal.



it up properly.



Empty the waste water tank by using the hose with the red







detach the floating unit.



floating unit.



Remove the brush.



Flush the brush with clear



Periodically check the valve



allow to dry.



Store the machine after working and leave the covers