





Suma Nova L6 Mini Guide


Available in 10 L SafePack



Use for cleaning:



Auto dosed dishwashing machines




Dishwashing detergent for medium/hard water



SafePack innovation

Using...



1

Use with Diversey auto dosed system or built-in dispenser.




2

When SafePack is empty, twist the connector ANTI-CLOCKWISE to disconnect.




3

Remove and dispose of empty pack.



4

Place open SafePack container onto the rack.



5

Ensure the pin on the cap aligns with the notch on the connector.



6

Attach the connector to the SafePack container with a CLOCKWISE push and twist. The alarm will sound if it is not connected fully.



7

Turn on machine.

