

## 1 Preparation

Take the TASKI procarpet 30, which can be used for spray extraction or encapsulation.

Fill fresh water into solution tank with a coupling hose or by using a bucket.

Depending on the application method dose the needed product into the fresh water.

Assemble the brush. Attention: Ensure you use the appropriated brush type.

Unwind power cord completely and plug it in.

## 6 Operation

Lower the brush and suction unit by pressing the foot pedal.

Adjust the brush position according to the floor.

Turn on the machine by pressing the On/Off button.

Choose the application mode you need.  
I. for encapsulation  
II for spray extraction.

Depending on the application method pre-spray the product onto the floor.

Clean the floor with the machine.

Or clean the floor by using a hand tool.

After work process is completed switch off the machine by pressing the On/Off button.

Lift-up the brush and suction unit by pressing the foot pedal.

Unplug the main cord and wind it up properly.

## Maintenance

Empty the waste water tank by using the hose with the red mark.

Empty fresh water into a sink through the blue marked draining hose or into a bucket by using the additional draining hose.

Flush out the solution and recovery tank.

Uncouple the recovery tank cover from the hoses and detach the floating unit.

Flush out the cover and the floating unit.

Remove the brush.

Flush the brush with clear water.

Clean brush housing after work process and check periodically the valve and the fresh water filter.

Dry the machine.

Store the machine after working and leave the covers open to allow air to circulate.

